




**ATTENTION:**

**Transgamme:** The new electrical system used by Citroen is called Transgamme.


DEFA CAN-bus alarm (Part no: 600862) can only be installed if the vehicle is equipped with Transgamme.

The vehicle is equipped with Transgamme if the text "PARKING/CLIENT" is typed above the shunt on the BSI (FUSE BOX).

This installation requires PSA-diagnostic tool, see page 4.






**NB!** This installation diagram must only be used as a guideline for the installation. Equipment delivered with the car varies considerably from model to model and from market to market. Before starting the installation, be sure to check carefully the original diagram from the car manufacturer. DEFA A.S is not liable to compensate for possible damages that may occur due to faulty or insufficient installation manuals.



**REQUIRED:**  
 - Alarm: CAN Alarm PSA  
 Minimum Central Unit rev: J  
 - Minimum Required SoftWare: 02




**GRY/YEL CONNECTOR**



**GRY CONNECTOR**





Attention!!

1. Install the DEFA alarm.
2. Connect the diagnostic tool, and choose installation of standard alarm.





