


7' DMP MONITOR MANUAL

MM107018V4


*FIRMWARE UPDATE(USB)

This monitor has a DMP & AUTO SYNC POWER function.




This model can be used for various functions, depending on the time (short / long) push of a button.

1. AV/IN : AV/3 video/audio input
2. Earphone : earphone output
3. Dimmer : (short) adjust brightness / (long) menu on/off
4. Left : (short) left / (long) volume: minus
5. Right : (short) right / (long) volume plus
6. Down : (short) down / (long) input source menu
7. Up : (short) up / (long) input source menu
8. Select : (short) select / (long) play
9. Power : power on/off
10. USB : usb input




1. Press the POWER button to turn on the product.
2. Press and hold the Dimmer button to launch the MENU.
3. Press the LEFT / RIGHT button to move to the OPTION menu.
4. Press the Up / Down button and the machine moves to 'software update (usb)'
5. Press the Select button to enter the UPDATE section.



6. Press the left button to launch the 'firmware update'.

7' DMP MONITOR MANUAL

*AUTO SYNC POWER function.
Auto Power function is automatically power on and check the input signal.(Except dmp mode)



1.video mode (hdmi1)
2.auto sync power on (Signal Detection)

*MENU



Restore Factory Default
Blending low
OsdDuration Off
Software Update(USB)

- Restore Factory : Use to initialize system.
- Blending : Use to adjust the transparency of menu.
- OsdDuration : Use to adjust menu display time.
- Software Update(USB) : Use to upgrade system.



Picture Mode Standard
Color Temperature Medium
Aspect 16:9
Noise Reduction Middle
Screen

SUB MENU

- Picture Mode : Use to choose the displaying condition.
- Color Temperature : Use to choose the color tone.
- Aspect : Use to control screen size.
- Noise Reduction : Use to adjust Strength of noise reduction.
- Screen : Use to adjust Vga screen.



Sound Mode Standard
Balance 0
Auto Volume Off
Surround Sound Off
EQ

SUB MENU

- Sound Mode : Use to choose the sound condition.
- Balance : Use to adjust Sound L/R Balance.
- Auto Volume : Use to enable Auto Volume function.
- Surround Sound : Use to enable Auto Surround function.
- EQ : Use to adjust Volume of each frequency.